


Duncan CONCEPTS

Tips & Techniques



- Concepts Underglazes should be fired to cone 06. In most cases they will be **dipped** in clear glaze before firing. However, 3-4 coats will create a shiny finish without dipping.
- For clear glaze application, brush-on or dip clear glaze over Concepts.
- For quick and easy solid coverage, try the **drop 'n fill** technique. Generously load a round brush with Concepts and drop color onto desired area. Let dry.
- Concepts colors mix and blend easily, so feel free to experiment with various combinations.
- These glazes come in a fun **“sprinkles”** style.